
USER MANUAL

Product Description



How to factory reset: When the camera is turned on. press and hold the reset button for about 3 seconds until the blue light and green light flash alternately

Device Description

slowly.

- This device has two modes: AP mode and WiFi mode
- Built-in battery.
- Support DC5V/2A power supply.

— 1 —

Indicator Status

charged.

fast flash --- during Wi-Fi connection. always bright --- Wi-Fi connection success. et: the blue light and green light flash alternately

Step 1: Pre-Setup

- Long press the Power Switch button 3 seconds to turn on
- Long press the reset button 3 seconds to factory reset.
- It's recommended to place the camera within 2 meters of the router for the first time connecting to the Internet.
- know the Wi-Fi connection password
- (Only 2.4GHz Wi-Fi is supported)

3 seconds to power off)

Yellow light: always bright during charging, goes off when fully

nt: slow flash---waiting for Wi-Fi connection,

rm: the blue light and green light flash rapidly at the same time.

- ✓ Connect the mobile phone to the router Wi-Fi. and
- (How to power off: Long press the power button for

— 3 —

Step 2:APP Download and Registration



1 Search for "O-KAM" in App Store or Google Play, or scan the QR cord to download the app.



2 Click "Register now", and then follow the prompts to register your account.

Step 3: Add Devices to the APP


welcome to use

Method One:Scan QR code to add camera

1 Click "Add" and scan the QR code on the camera, or

— 4 —

directly select "Wireless camera".



- restore the factory
- 2 Turn on the camera and 3 Confirm the Wi-Fi you want to connect and enter the correct password.(5G Hz netwo are not supported)


— 5 —



Scan the QR code


△ Scan the QR code generated ⑤ After the camera is successfully connected to the internet, click "Get started"


Method Two:AP Connection




- page, and select "Hotspot configuration"
- 1 Click the icon in the 2 Click "To connect". upper right corner of the

✓ @MC-123456









5 Click "Device 6 Click "Wi-Fi 7 Select the Wi-Fi Settings". network".

— 9 —

Enter the "Settings" interface of the camera and select "Share" to generate the device sharing QR code. Other users open the APP, click the "Add" button on the home

Device Share

----10 ----

page, and then scan the QR code to add the device.

— 7 —

— 8 —

signal to be connected and enter the correct password, then

click "Confirm".

← QR code sharing

UID: INSURENCE AND ADDRESS OF THE PARTY OF T